

Using data file "PKPlusDeviceFile.dat" which is a version 2.63.217 file.

PIC32MX460F512L	Others/PIC32	0x00078000									
PIC32MX460F256L	Others/PIC32	0x00074000									
PIC32MX440F512H	Others/PIC32	0x00056000									
PIC32MX440F256H	Others/PIC32	0x00052000									
PIC32MX440F128L	Others/PIC32	0x0006D000									
PIC32MX440F128H	Others/PIC32	0x0004D000									
PIC32MX420F032H	Others/PIC32	0x00042000									
PIC32MX360F512L	Others/PIC32	0x00038000									
PIC32MX360F256L	Others/PIC32	0x00034000									
PIC32MX340F512H	Others/PIC32	0x00016000									
PIC32MX340F256H	Others/PIC32	0x00012000									
PIC32MX340F128L	Others/PIC32	0x0002D000									
PIC32MX340F128H	Others/PIC32	0x0000D000									
PIC32MX320F128L	Others/PIC32	0x0002A000									
PIC32MX320F128H	Others/PIC32	0x0000A000									
PIC32MX320F064H	Others/PIC32	0x00006000									
PIC32MX320F032H	Others/PIC32	0x00002000									
PIC32MX250F128B	Others/PIC32	0x04D00053									
PIC32MX230F064B	Others/PIC32	0x04D01053									
PIC32MX220F032B	Others/PIC32	0x04A00053									
PIC32MX210F016B	Others/PIC32	0x04A01053									
PIC32MX150F128B	Others/PIC32	0x04D06053									
PIC24HJ64GP510	Others/PIC24	0x0000004B	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP506	Others/PIC24	0x00000049	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP504	Others/PIC24	0x000000677	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP502	Others/PIC24	0x000000675	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP210	Others/PIC24	0x00000047	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP206	Others/PIC24	0x00000041	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP204	Others/PIC24	0x000000657	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ64GP202	Others/PIC24	0x000000655	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ32GP304	Others/PIC24	0x000000647	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ32GP302	Others/PIC24	0x000000645	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ32GP204	Others/PIC24	0x00000F1F	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ32GP202	Others/PIC24	0x00000F1D	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ256GP610	Others/PIC24	0x0000007B	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ256GP210	Others/PIC24	0x00000073	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ256GP206	Others/PIC24	0x00000071	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ16GP304	Others/PIC24	0x00000F17	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ12GP202	Others/PIC24	0x0000080B	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ12GP201	Others/PIC24	0x0000080A	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP510	Others/PIC24	0x00000063	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP506	Others/PIC24	0x00000061	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP504	Others/PIC24	0x00000067F	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP502	Others/PIC24	0x00000067D	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP310	Others/PIC24	0x00000067	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP306	Others/PIC24	0x00000065	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP210	Others/PIC24	0x0000005F	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP206	Others/PIC24	0x0000005D	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP204	Others/PIC24	0x000000667	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24HJ128GP202	Others/PIC24	0x000000665	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FV32KA301	Others/PIC24	0x00004519	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ96GA010	Others/PIC24	0x0000040C	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ96GA008	Others/PIC24	0x00000409	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ96GA006	Others/PIC24	0x00000406	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GB110	Others/PIC24	0x00001007	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GB108	Others/PIC24	0x00001003	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GB106	Others/PIC24	0x00001001	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GB004	Others/PIC24	0x0000420F	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GB002	Others/PIC24	0x00004207	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GA104	Others/PIC24	0x0000420E	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GA102	Others/PIC24	0x00004206	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GA010	Others/PIC24	0x0000040B	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	
PIC24FJ64GA008	Others/PIC24	0x00000408	*	Programmer	to Go	Supported	- PICKit2	Programmer Only	using PICKitPlus	GUI application	





























93LC46B (C x16)	EEPROMS/93LCxB,C	0xFFFFFFFF	*
93LC46A (C x8)	EEPROMS/93LCxA,C	0xFFFFFFFF	*
25LC640A	EEPROMS/25LC	0xFFFFFFFF	*
25LC512	EEPROMS/25LC	0xFFFFFFFF	*
25LC320A	EEPROMS/25LC	0xFFFFFFFF	*
25LC256	EEPROMS/25LC	0xFFFFFFFF	*
25LC160B	EEPROMS/25LC	0xFFFFFFFF	*
25LC160A	EEPROMS/25LC	0xFFFFFFFF	*
25LC128	EEPROMS/25LC	0xFFFFFFFF	*
25LC1024	EEPROMS/25LC	0xFFFFFFFF	*
25LC080B	EEPROMS/25LC	0xFFFFFFFF	*
25LC080A	EEPROMS/25LC	0xFFFFFFFF	*
25LC040A	EEPROMS/25LC	0xFFFFFFFF	*
25LC020A	EEPROMS/25LC	0xFFFFFFFF	*
25LC010A	EEPROMS/25LC	0xFFFFFFFF	*
24xx64	EEPROMS/24xx	0xFFFFFFFF	*
24xx512	EEPROMS/24xx	0xFFFFFFFF	*
24xx32	EEPROMS/24xx	0xFFFFFFFF	*
24xx256	EEPROMS/24xx	0xFFFFFFFF	*
24xx16	EEPROMS/24xx	0xFFFFFFFF	*
24xx128	EEPROMS/24xx	0xFFFFFFFF	*
24xx1026	EEPROMS/24xx	0xFFFFFFFF	*
24xx1025	EEPROMS/24xx	0xFFFFFFFF	*
24xx08	EEPROMS/24xx	0xFFFFFFFF	*
24xx04	EEPROMS/24xx	0xFFFFFFFF	*
24xx02	EEPROMS/24xx	0xFFFFFFFF	*
24xx01	EEPROMS/24xx	0xFFFFFFFF	*
24xx00	EEPROMS/24xx	0xFFFFFFFF	*
24LC32A	EEPROMS/24xx	0xFFFFFFFF	*
24LC16B	EEPROMS/24xx	0xFFFFFFFF	*
24LC08B	EEPROMS/24xx	0xFFFFFFFF	*
24LC04B	EEPROMS/24xx	0xFFFFFFFF	*
24LC02B	EEPROMS/24xx	0xFFFFFFFF	*
24LC01B	EEPROMS/24xx	0xFFFFFFFF	*
11LC160	EEPROMS/11LC	0xFFFFFFFF	*
11LC080	EEPROMS/11LC	0xFFFFFFFF	*
11LC040	EEPROMS/11LC	0xFFFFFFFF	*
11LC020	EEPROMS/11LC	0xFFFFFFFF	*
11LC010	EEPROMS/11LC	0xFFFFFFFF	*
+FL127S	EEPROMS/25LC	0xFFFFFFFF	*

\* Supported by PKCMD, PKAutoWatch, PKGangProgrammer and PKCMD-LX.

All devices are supported by PICKit2Plus and PICKit3Plus applications.